

Repair parts

Units using 8 Watt T5 lamps

Item description	L.C. Doane part number	Military number	NSN number
Lamp	P-1	MS15588-3	6240-00-294-5546
Red filter tube	B-1812-S	M16377/42A-001	6210-00-399-6297
Amber filter tube	B-2264-S	M16377/42	
Blue filter tube	B-1827-S	M16377/42-002	6210-00-503-2810
Grey filter tube (1.0%)	B-2033-S	M16377/42-013	6210-01-351-3943
Grey filter tube (2.5%)	B-2025-S	M16377/42-014	6210-01-313-8170
Ballast	P-340-S	M16377/45A-001	6250-00-295-2735
Lampholder	P-2-S	UL542	6250-00-377-8590
Lamplock	B-31-S	M16377/40-001	6250-00-399-7039
Starter socket	P-4-S	UL542	6250-00-295-2738
Starter	P-5-S	Type III of W-S-755 (FS-5)	6250-00-299-5962
Toggle switch DPST	P-573-S	MS16569-1	5930-00-719-9659

Units using T12 lamps

Item description	L.C. Doane part number	Military number	NSN number
Lamp (15 W)	P-1097	W-L-116/13	6240-00-583-3668
Lamp (17 W)	P-1746	A-A-50597	6240-01-456-7015
Lamp (20 W)	P-858	M-15589-4	6240-00-152-2996
Red filter tube (17 & 20 W)	B-1634-S	M16377/42-003	6210-00-295-2838
Red filter tube (15 W)	B-1635-S	M16377/42-004	6210-00-834-1621
Amber filter tube	B-1884-S	M16377/42-006	6210-01-166-7184
Blue filter tube	B-838-AS	M16377/42-005	6210-00-441-5138
Grey filter tube (1.0%)	B-2034-S	M16377/42-007	
Grey filter tube (2.5%)(17 & 20W)	B-2026-S	M16377/42-009	6210-01-313-8168
Grey filter tube (2.5%)(15 W)	B-2026-AS	M16377/42-010	6210-01-313-8169
Ballast (17 W)	P-1739-S	M16377/72-001	
Ballast (20 W)	P-1149-S	M16377/44-001	6250-00-569-9502
Lampholder	P-116-S	UL542	6250-00-284-0481
Lamplock	B-222-1-S	M16377/40-002	6250-00-399-7040
Starter socket	P-4-S	UL542	6250-00-295-2738
Starter	P-119-S	Type III of W-S-755 (FS-2)	6250-00-299-2884
Toggle switch DPST	P-573-S	MS16569-1	5930-00-719-9659

Additional repair parts for NEALS emergency fixtures

Item description	L.C. Doane part number	Military number	NSN number
NEALS Ballast	P-2183-H	M16377/77-001	
Indicator light (LED)	A-3337-S	M16377/	6220-01-415-7889
Test switch (push)	A-3334-S	M16377/	5930-01-416-0342
Test switch (pull)	P-573-S	MS16569-1	5930-00-719-9659
Battery enable switch	A-3322-S	M16377/	5930-01-414-9240
Ballast enclosure	A-3442-S	M16377/	